






RANGE NAME: BOXY




BOXY 90cm MINI
ARM CHAIR




BOXY 100cm MIDI
ARM CHAIR




BOXY 110cm MAXI
ARM CHAIR



BOXY 150cm MINI ARM SOFA



BOXY 160cm MIDI ARM SOFA



BOXY 170cm MAXI ARM SOFA




BOXY 170cm MINI ARM SOFA




BOXY 180cm MIDI ARM SOFA




BOXY 190cm MAXI ARM SOFA




WOOD SCREW




WOOD FOOT



SUPPORT LEG



WOOD FOOT



WOOD FOOT



RANGE NAME: BOXY




BOXY 190cm MINI ARM SOFA




BOXY 200cm MIDI ARM SOFA




BOXY 210cm MAXI ARM SOFA




BOXY 210cm MINI ARM SOFA




BOXY 220cm MIDI ARM SOFA




BOXY 230cm MAXI ARM SOFA



BOXY 230cm MINI ARM SOFA




BOXY 240cm MIDI ARM SOFA




BOXY 250cm MAXI ARM SOFA


RANGE NAME: ARCHY




ARCHY 90cm MINI ARM CHAIR




ARCHY 100cm MIDI ARM CHAIR




ARCHY 110cm MAXI ARM CHAIR




ARCHY 150cm MINI ARM SOFA




ARCHY 160cm MIDI ARM SOFA




ARCHY 170cm MAXI ARM SOFA




ARCHY 170cm MINI ARM SOFA




ARCHY 180cm MIDI ARM SOFA




ARCHY 190cm MAXI ARM SOFA




M6 × 40mm
MACHINE SCREW




40 × 105mm
WOOD FOOT



SUPPORT LEG



40 × 155mm
WOOD FOOT



40 × 205mm
WOOD FOOT



RANGE NAME: ARCHY




ARCHY 190cm MINI ARM SOFA




ARCHY 200cm MIDI ARM SOFA




ARCHY 210cm MAXI ARM SOFA




ARCHY 210cm MINI ARM SOFA




ARCHY 220cm MIDI ARM SOFA




ARCHY 230cm MAXI ARM SOFA



ARCHY 230cm MINI ARM SOFA



ARCHY 240cm MIDI ARM SOFA



ARCHY 250cm MAXI ARM SOFA